MM300 / MM301 Sweex eBook Reader Quick Start Guide

I. Interface and control buttons





1. Power	**7.** SD card slot
2. Bookmark	**8.** Volume/Size Adjust
3. Rotate Screen	**9.** Reset
4. Return	**10.** 2.5mm Headphone Jack
5. Option Menu (Library and Reading)	**11.** USB port & AC Power Adapter port
6. Cursor key and Select Button port	

II. Reading Operation



✓	Select (Or bring up option menu, when in reading)
▲	Previous Item
▼	Next Item
◀	Previous Page
▶	Next Page

III. Manual

There are two ways to access the full manual, which is stored on the reader as a PDF eBook itself:

1. Connect the USB Cable and read or print the manual with your computer. The manual is in the "Manual" folder.
2. Read the manual on the eBook reader itself. To do this, follow these steps:

    - Select "Library" and press the select button.
    - Use the "Next Item" button to go to the Manual folder and press "Select" again
    - Use the "Next Item" button to go to the eBook Reader Manual and press "Select". The manual will now open on screen.